

User Manual

XTireProbe-TPMS Diagnostic Tool



High-efficiency Smart Portable

*Please read this manual in full before use

Trademarks

 is trademark of Shenzhen Xtooltech Intelligent Co., Ltd. Copyright, registered in China, the United States, and other countries. All other marks are trademarks or registered trademarks of their respective holders.

Disclaimer of Warranties and Limitation of Liabilities

All information, specifications and illustrations in this manual are based on the latest information available at the time of printing.

Xtool reserves the right to make changes at any time without notice. While information of this manual has been carefully checked for accuracy, no guarantee is given for the completeness and correctness of the contents, including but not limited to the product specifications, functions, and illustrations.

Xtool will not be liable for any direct, special, incidental, or indirect damages, or for any economic consequential damages (including the loss of profits) as a result of using this product.

 Before operating or maintaining this unit, please read this manual carefully, paying extra attention to the safety warnings and precautions.

Support & Service

Official Website: www.xtooltech.com

Tel: +86 755 21670995 or
+86 755 86267858 (China)

E-mail: supporting@xtooltech.com

Safety Information

For your own safety and the safety of others, and to prevent damage to the device and vehicles upon which it is used, it is important that the safety instructions presented throughout this manual be read and understood by all persons operating or coming into contact with the device.

There are numerous procedures, techniques, tools, and parts required for servicing vehicles, as well as the skills of the person doing the work. Because of the vast number of test applications and variations in the products that can be tested with this equipment, we cannot possibly anticipate or provide advice or safety messages to cover every circumstance. It is the automotive technician's responsibility to be knowledgeable of the system being tested. It is crucial to use proper service methods and test procedures. It is essential to perform tests in an appropriate and acceptable manner that does not endanger your safety, the safety of others in the work area, the device being used, or the vehicle being tested.

Before using the device, always refer to and follow the safety messages and applicable test procedures provided by the manufacturer of the vehicle or equipment being tested. Use the device only as described in this manual. Be sure to read, understand, and follow all safety messages and instructions in this manual.

Safety Instructions

The safety messages herein cover situations Xtool is aware of at the time of publication. Xtool cannot know, evaluate or advise you as to all of the possible hazards. You must be certain that any condition or service procedure encountered does not jeopardize your personal safety.

Catalogue

1. Safety Precautions	1
2. General Introduction	2
2.1 Description	2
2.2 Equipment Specifications	3
2.2.1 Tablet Specifications	3
2.2.2 Slave Device Specifications	4
2.3 Battery & Charge	4
3. Product Use	5
3.1 Product Activation	5
3.2 Device Connection	7
3.3 Application Button	7
4. Function Introduction	9
4.1 TPMS	9
4.1.1 Intelligent Mode (Vehicle Recognition)	9
4.1.2 Manual Mode(Vehicle Recognition)	10
4.2 Trigger the sensor	11
4.3 TPMS Diagnostic	13
4.4 Program the sensor	14
4.4.1 Activate Copy	14
4.4.2 OBD Copy	15
4.4.3 Copy By Input	16
4.4.4 Auto Create	17
4.5 Relearn	19
4.5.1 OBD Relearn	19
4.5.2 Automatic Relearn	20
4.6 OE query	22
4.6.1 Trigger the sensor	22
4.6.2 Program the sensor	23
4.6.3 Support	26
4.7 Sensor Test	27
4.8 TPMS Toolbox	28

4.9 Test Record	29
4.10 Updates	32
4.11 Diagnosis	34
4.12 Auto Scan	37
4.13 Special Function	38
4.13.1 Oil Reset.....	38
4.13.2 Throttle Adaptation	40
4.13.3 BMS Reset	41
4.13.4 EPS Adaption	43
4.13.5 EPB Reset	44
4.13.6 ABS Bleeding	46
4.13.7 DPF Regen	47
4.13.8 Injector Coding	48
4.13.9 TPMS Reset.....	49
4.14. OBD II	51
4.15 Report Center	52
4.16 Settings	53
5. Warranty and service support.....	55
5.1 One-year valid warranty period	55
5.2 Service and Support.....	55
Compliance Information	56
FCC Compliance	56
Warning	56
Note	56
ISED Statement	56
CE	57
UKCA.....	57

1. Safety Precautions

- This manual contains the equipment operating instructions.
- Some illustrations in this manual may show modules or optional equipment not included in your system. Please contact your sales representative for information or purchase.

· Notes and Precautions

Note:

This section provides supplementary instructions, operational tips, and recommendations to enhance user experience and system performance.

· Precautions:


This section highlights critical situations that must be avoided to prevent damage to diagnostic equipment or vehicle systems.

· Illustrations

The illustrations in this manual are for reference only. Actual test interfaces may vary depending on the vehicle under diagnosis. Always observe menu titles and on-screen prompts to ensure correct selections.

① 2. GENERAL INTRODUCTION

2.1 Description



Illustrations may differ from actual product. Refer to actual product for exact specification

①Power Button


②Touch-Screen

③Sensor activation area

④Type-C Port

⑤SD card Slot

⑥Nameplate



①OBD Port

②Type-C Port

③Indicator Light

Indicator light instructions

The green light stays on continuously:Power is connected, but not linked to the device host.

The green light is flashing:VCI firmware update

The blue light stays on continuously:The device is connected but not communicating with the vehicle.

The blue light is flashing:The device is successfully connected and communicating with the vehicle.

The red light is flashing:VCI fault

2.2 Equipment Specifications

2.2.1 Tablet Specifications

Project	Specifications
Screen	720*1440 5.45" touch screen
Operating Temperature	-10°C~50°C
Storage Temperature	-40°C~70°C
Dimension	179.9mm*89.7mm*30.07mm
Weight	0.35kg(0.77lb)

2.2.2 Slave Device Specifications

Project	Specifications
Operating Temperature	-10°C~50°C
Storage Temperature	-40°C~70°C
Dimension	70mm*50mm*36mm
Weight	0.07kg (1.70lb)

2.3 Battery & Charge

· Use a USB cable to connect to a PC and charge the battery.

· Charge the battery using a Power charger:

1. Locate and open the protective cover on the device's USB port.
2. Use the USB cable adapter to connect the device and the power supply.

· To maintain the optimal performance of the product, please fully charge it each time. It is recommended that you charge it for at least 2 hours before the first use.

Warning:

- 1) Only use the USB cable adapter provided in our accessories to charge this device. Damage to the product or malfunction caused by using an unapproved power source is not covered by our warranty.
- 2) This product is equipped with a built-in 4500mAh/3.6V lithium-ion polymer rechargeable battery. The battery can be recharged repeatedly, but please note that as a consumable component, prolonged use will gradually reduce the device's standby time. To extend battery lifespan, avoid frequent recharging.

3. Product Use

3.1 Product Activation


For the first use, you need to activate and initialize the device. Simply follow the system prompts to complete the activation and initialization process. Upon successful activation, a confirmation message will be displayed.

1. Select Device Language (Figure 1).




(Figure 1)

2. Connect to Wi-Fi Network (Figure 2).



(Figure 2)


3. After the device successfully connects to the network, tap [Next] to download (Figure 3) and install (Figure 4) the software package.



(Figure 3)

(Figure 4)


4. Proceed to [Register] (Figure 5)/[Log in] (Figure 6) After Download Completes.



(Figure 5)

(Figure 6)

5. Product Successfully Activated (Figure 7).



(Figure 7)

3.2 Device Connection

Icons	Description
	The device is connected to the network.
	The VCI has been connected to the tire pressure diagnostic device.
	The VCI is not connected to the tire pressure diagnostic device.

3.3 Application Button

Button	Description
	Access the tire pressure system for diagnosis; for details, refer to "Tire Pressure Monitoring" on page 9.

 OE Query	Query the information of OE number. For details, refer to "OE Query" on page 22.
 Sensor Test	Activate the sensor and read the information stored inside it. For details, refer to "Sensor Test" on page 27.
 TPMS Toolbox	This menu includes the key frequency detection function; For details, refer to "TPMS Toolbox" on page 28.
 Test Records	View all test records; For details, refer to "Test Records" on page 39.
 Updates	Provide upgrade and update services; For details, refer to "Updates" on page 32.
 Diagnosis	Select vehicle modules for information reading and diagnosis; For details, refer to "Diagnosis" on page 34.
 Auto Scan	Identify the vehicle. For details, please refer to "Auto Scan" page 37.
 Special Functions	Provide multi-module special functions; For details, refer to "Special Functions" on page 38.
 OBD II	Select the communication protocol to diagnose the diagnostic system; For details, refer to "OBD II" on page 51.
 Report Center	View your personal account; For details, refer to "Report Center" on page 52.
 Settings	Access the system's general settings menu; For details, refer to "Settings" on page 53.

4. Function Introduction

4.1 TPMS

Access the [tire pressure monitoring] option on the homepage to perform basic tire pressure system monitoring functions (activating tire pressure sensors, diagnosing the tire pressure system, programming tire pressure sensors, viewing learning procedures and sensor information).

4.1.1 Intelligent Mode (Vehicle Recognition)

1. Turn on the device, click [TPMS] (Figure 1) to enter the vehicle selection interface. Select [Intelligent Mode] (Figure 2).



(Figure 1)




(Figure 2)

2. After confirming that the ignition switch is turned on and the tire pressure device is connected to the VCI normally, wait for the VIN to be read.

4.1.2 Manual Mode(Vehicle Recognition)

1.Turn on the device, click [TPMS] to enter the vehicle selection interface. Select [Manual Mode] (Figure 3).



(Figure 3)


2.Vehicle selection: Market region → Brand → Model → Year of manufacture. (Figure 4)



(Figure 4)


4.2 Trigger the sensor

1. Select the [Check] interface (Figure 1).



(Figure 1).


2. Hold the device close to the sensor of the highlighted wheel in the device test interface (usually located at the valve), and click [Start Trigger] to activate it (Figure 2).



(Figure 2)


3. After successfully activating the sensors, information of all activated sensors will be displayed (Figure 3).

※ If any sensor fails to activate, please repeat the activation procedure according to the device prompts.



(Figure 3).


4. If the sensor battery is low, a low-battery icon will be displayed (Figure 4).



(Figure 4).

4.3 TPMS Diagnostic

1. Select the [Diagnostics] interface (Figure 1). Turn on the vehicle's ignition switch, and insert the wireless slave VCI diagnostic box into the vehicle's OBD port (usually located under the steering wheel) to complete the communication connection.



(Figure 1)

2. After the VCI completes the communication connection, click [Diagnose] to acquire data and perform fault diagnosis. The device will display the information of all vehicle sensors and read whether there are fault codes (Figure 2).

※ If communication fails, please check whether the connection is secure, whether the vehicle's ignition switch is turned on, or whether the vehicle model is supported, then repeat the operation.



(Figure 2)

4.4 Program the sensor


4.4.1 Activate Copy

1. Enter the [Programming] page (Figure 1), select the tire pressure sensor to be programmed, hold it close to the upper end of the device, and click the [Activate Copy] option.



(Figure 1)

2. Select the sensor ID of the originally tested vehicle that has been activated to perform copying (Figure 2).



(Figure 2)

3. After completing the scan, the detected sensor SN numbers will be displayed. Select the corresponding SN number and proceed to programming

4. Complete the sensor programming.

4.4.2 OBD Copy

1. Enter the [Programming] page (Figure 1), select the tire pressure sensor to be edited, hold it close to the upper end of the device, and click the [OBD Copy] option.



(Figure 1)

2. Follow the device instructions to connect the device to the OBD diagnostic socket of the test vehicle for communication.

※ If communication fails, please retry starting from the [Programming] interface (Figure 1).


3. After the communication is completed, the sensor SN numbers of the test vehicle will be displayed. Select the corresponding SN number and click [OBD Copy] to perform programming.

4. Complete the sensor programming.

4.4.3 Copy By Input

1. Enter the [Programming] page (Figure 1), select the tire pressure sensor to be edited, place it close to the upper end of the device, and click the [Copy By Input] option.

※ Manual ID input only supports operation on one sensor at a time.



(Figure 1)

2. After completing the scan, enter the ID editing interface (Figure 2), confirm the ID format, and then customize the ID.




(Figure 2)

3. After entering the ID, write this ID into the sensor.

4. Complete the sensor programming.


4.4.4 Auto Create

1. Enter the [Programming] page (Figure 1), select the tire pressure sensor to be edited, place it close to the upper end of the device, and click the [Auto Create] option.



(Figure 1)

2. After completing the scan (Figure 2), the detected sensor SN number will be displayed. Select the corresponding SN number for programming (Figure3).



(Figure 2)



(Figure 3)

3. This function also supports programming multiple sensors simultaneously. When multiple sensors are within the sensing range of the device, it will jump to the interface as shown in (Figure 4). Select the sensors to be programmed or select all scanned sensors, then click [Programming/All Programming] to perform the programming.



(Figure 4)

4. After the progress is completed, the device has written the automatically generated ID into the target sensor (Figure 5).



(Figure 5)

4.5 Relearn

4.5.1 OBD Relearn

1. Select the [Relearn] interface (Figure 1), set the vehicle gear to P (Park), and pull up the handbrake.
2. On the TP800, select the sensor, click [Start Trigger], and activate each sensor in sequence according to the order of left front, right front, right rear, left rear, and spare tire (if available) (Figure 1).



(Figure 1)

3. After installing the tire pressure sensors, inflate all tires to the standard pressure (usually found on the door frame), and keep the vehicle stationary for 5-10 minutes.

4. Connect the TPMS tool to the vehicle's OBD interface, turn on the ignition switch, and click [OBD Learning] (Figure 2).




(Figure 2)

5. Turn off the ignition switch and then turn it on again. Drive at a speed higher than 30km/h for more than 10 minutes to ensure the tire pressure warning light goes off.

4.5.2 Automatic Relearn

1. Select the [Learning] interface (Figure 1). Inflate all tires to the standard pressure (usually found on the door frame) and pull up the parking brake.



(Figure 1)


2.The vehicle must remain stationary for 20 minutes to allow the control module to enter learning mode.

3.Drive the vehicle at a speed of 25-100km/h to learn the sensor ID.Reset the tire pressure value:


- ① Inflate all tires to the standard pressure (usually found on the door frame), pull up the parking brake, and then turn on the ignition switch (with the engine off).
- ② Press and hold the 'Set (or ESP)' button (located near the gear shifter) until a prompt tone sounds, indicating that the learning is completed.

4.6 OE query

1. Turn on the device, select [OE Query] (Figure 1), and enter the OE number list (Figure 2).




(Figure 1)



(Figure 2)


4.6.1 Trigger the sensor

1. After completing the selection of the OE number, you will be redirected to the 'Check' interface (Figure 1).



(Figure 1)

2. Select the ID and click [Start Trigger] to trigger the sensor (Figure 2).




(Figure 2)

3. Complete the activation of the sensor.

4.6.2 Program the sensor

Click [Programming] to enter the ID selection interface (Figure 1).



(Figure 1)

4.6.2.1 Activate Copy

1.Bring the device close to the sensor to be programmed. After the scan is completed, the sensor SN number of the test vehicle will be displayed.


2.Select the corresponding sensor SN number, click [Activate Copy], and enter programming.

3.Complete the writing of the programming.

4.6.2.2 Copy By Input

1.Bring the device close to the sensor to be programmed. After communication is completed, select the SN code of the sensor to be programmed.

2.Click [Copy By Input], confirm the ID format, and then customize the ID (Figure 1).



(Figure 1)


3.After entering the ID, write this ID into the sensor to start programming.

4.Complete the sensor programming.

4.6.2.3 Auto Create

1. Bring the device close to the sensor to be programmed. After the communication is completed, select the SN - code of the sensor to be programmed.

2. Click [Auto Create] to scan the sensor and automatically create an ID to write into the sensor (Figure 1).



(Figure 1)

3. This function also supports programming multiple sensors simultaneously, and the specific operation process is consistent with that of 4.4.4 Auto Create.

4. Complete the sensor programming.

4.6.3 Support


1. Select [Support] to jump to the interface corresponding to the vehicle model of the OEM sensor. (Figure 1).



(Figure 1)

2. Select the vehicle model and click [Enter Vehicle] to enter the interface of the **4.1 TPMS** function (Figure 2).

※The function is the same as that of **4.1**.



(Figure 2)

4.7 Sensor Test

1. Turn on the device, click [Sensor Test] (Figure 1), and switch to the sensor detection interface (Figure 2).



(Figure 1)



(Figure 2)

2. Click [Start Detection] to get the detection result (Figure 3).

※ Only sensors from Langren Technology Co., Ltd. are supported for detection.



(Figure 3)

4.8 TPMS Toolbox

1. Turn on the device, click [TPMS Toolbox] (Figure 1), and switch to the tire pressure toolbox interface (Figure 2).




(Figure 1)



(Figure 2)

2. Click on the [Key Frequency Detection] function.

3. Obtain the test result (Figure 3).




(Figure 3)

4.9 Test Record

1. Turn on the device, click [Test Records] (Figure 1), and switch to the test records interface (Figure 2).



(Figure 1)



(Figure 2)

2. Select the test records of the corresponding date, expand them, and you will get the test record list column (Figure 3).




(Figure 3)

3. Select the corresponding test record to obtain the diagnostic report (Figure 4).




(Figure 4)

4. Click [Share] to pop up the email input box for report sharing (Figure 5).



(Figure 5)

5. After expanding the corresponding test record column, click '  ' to enter the **4.1 TPMS** function interface (Figure 6).



(Figure 6)

4.10 Updates

1. Turn on the device, click [Updates] (Figure 1), and jump to the update package menu (Figure 2).



(Figure 1)



(Figure 2)

2. Click the upgrade package bar to pop up specific optimization details (Figure 3).



(Figure 3)

3. Click on the '⬇️' corresponding to the selected upgrade package to perform the upgrade.

4. Click [One - click Upgrade] below to upgrade all upgradeable installation packages (Figure 4).




(Figure 4)

4.11 Diagnosis

1. Open the device and click [Diagnosis] (Figure 1) to jump to the vehicle - model selection interface (Figure 2).




(Figure 1)



(Figure 2)

2. After selecting the vehicle model, wait for the VCI firmware to be upgraded (Figure 3).




(Figure 3)

3. Automatic Detection/Manual Selection (Figure 4).




(Figure 4)

4. Automatic Detection: Perform an automatic scan of the condition of the vehicle modules (Figure 5).



(Figure 5)

5. System Selection: Select the control module to be read (Figure 6).




(Figure 6)

6. ①Read ECU Information ②Read DTC ③Clear DTC (Figure 7).



(Figure 7)

7. After reading is completed, [Report Details] will pop up when exiting Diagnosis (Figure 8). Click [OK] to save the diagnostic report to the 4.15 Report Center.



(Figure 8)

4.12 Auto Scan

1. Turn on the device and click [Auto Scan] (Figure 1) to enter the interface (Figure 2). Select Auto Scan or Manual Input for vehicle identification.



(Figure 1)




(Figure 2)

4.13 Special Function



4.13.1 Oil Reset

1. Enter [Special Functions] → select [Oil Reset] (Figure 1).



(Figure 1)


2. Automatic Detection/Manual Selection (Figure 2).



(Figure 2)

3. Select vehicle control module.


4. select according to the prompts to complete the Oil Reset(Figure3).



(Figure3)

4.13.2 Throttle Adaptation


1. Enter [Special Functions] → select [Throttle Adaptation] (Figure 1).



(Figure 1)

2. Automatic Detection/Manual Selection.

3. Select the automotive control module (Figure 2).




(Figure 2)

4. complete the operation according to the option prompts (Figure 3)(Figure 4).



(Figure 3)



(Figure 4)

4.13.3 BMS Reset

1. Enter [Special Functions] → select [Throttle Adaptation] (Figure 1).



(Figure 1)

2. Automatic Detection/Manual Selection.

3. Select the function (Figure 2).



(Figure 2)


4. Please complete the operation as prompted according to your needs (Figure 3).



(Figure 3)

4.13.4 EPS Adaption

1. Enter [Special Functions] → select [EPS Adaptipn] (Figure 1).



(Figure 1)


2. Automatic Detection/Manual Selection.

3. Select the vehicle control unit (Figure 2).




(Figure 2)

4. Perform the EPS Adaption operation according to specific instructions, illustration: (Figure 3)(Figure 4)




(Figure 3)



(Figure 4)

4.13.5 EPB Reset

1. Enter [Special Functions] → select [EPB Reset] (Figure 1).



(Figure 1)

2. Automatic Detection/Manual Selection.

3. Select the vehicle control unit (Figure 2).



(Figure 2)


4. Choose the function and complete the EPB Reset operation as per the prompts (Figure 3).



(Figure 3)

4.13.6 ABS Bleeding

1. Enter [Special Functions] → select [ABS Bleeding] (Figure 1).




(Figure 1).

2. Automatic Detection/Manual Selection.

3. Select the brake system bleeding procedure.


4. Perform the ABS bleeding operation as instructed (Figure 2).



(Figure2)

4.13.7 DPF Regen


1. Enter [Special Functions] → select [DPF Regen] (Figure 1).



(Figure 1)

2. Automatic Detection/Manual Selection.

3. Select the vehicle control unit (Figure 2).



(Figure 2)


4. Perform the DPF Regen operation as instructed (Figure 3).



(Figure 3)

4.13.8 Injector Coding

1. Enter [Special Functions] → select [Injector Coding] (Figure 1).



(Figure 1)

2. Automatic Detection/Manual Selection.


3. Perform the DPF Regen operation as instructed (Figure 2).



(Figure 2)


4.13.9 TPMS Reset

1. Enter [Special Functions] → select [TPMS Reset] (Figure 1).



(Figure 1)

2. Select the TPMS corresponding to the country (Figure 2).



(Figure 2)

3. Select the test record or vehicle model (Figure 3).



(Figure 3)

4. Select the required function in the figure (Figure 4).



(Figure 4)

4.14. OBD II

1. Turn on the device, select [OBD II] (Figure 1), and enter the function selection interface (Figure 2).



(Figure 1)



(Figure 2)

2. Select the relevant communication protocol and function.

3. The diagnostic system performs diagnostics.

4.15 Report Center

1. Turn on the device, select [Report Center] (Figure 1).



(Figure 1)

2. This function supports viewing user diagnostic reports (Figure 2), Click to access and view (Figure 3).



(Figure 2)



(Figure 3)

4.16 Settings



(Figure 1)



(Figure 2)

1. **[Language]:** Set the language

2. **[Unit]:** Set metric, imperial, or US customary units

3. **[Tire - Pressure Settings]:**

①Market region: Select country

②Pressure unit: Set the pressure unit to kPa, Psi, or Bar.

③Temperature unit: Set the temperature unit to degrees Celsius or degrees Fahrenheit

④Sensor ID format: Set to automatic, hexadecimal, or decimal.

4. **[WiFi connection]:** Select a network to connect to the Internet.

5. **[Display]:**

①Screen brightness: Drag the slider to adjust the brightness.

②Sleep time: Set the sleep time to 15s, 30s, 1min, 5min, 10min or never.

6. **[Storage]:**

①File Management → Internal Storage: Select a file to view.

②Diagnostic storage settings: Set to intelligent storage or system storage

③The used space of the internal - storage is directly displayed by both a horizontal bar and numbers.

- ④Clear cache: Click to clean immediately without confirmation.

7. [Date & Time]:

- ①Time - zone settings: Multiple time zones are available for selection.
- ②Time format: Set to 24 - hour or 12 - hour format.

[About]: Show device information like

- ①Model
- ②VCI Serial Number
- ③OS Serial Number
- ④MAC Address
- ⑤Version Number
- ⑥Factory Data Reset

8. **[Upload test report to the cloud]:** Once opened, the diagnostic report can be shared with the cloud.

5. Warranty and service support

5.1 One-year valid warranty period

Shenzhen Yunjia Intelligent Technology Co., Ltd. (hereinafter referred to as "the Company") warrants to the original retail purchaser of this device that, within one year from the date of delivery, under normal usage conditions, if the device malfunctions due to any defect in materials or workmanship, the Company will, upon presentation of the purchase certificate, repair or replace the device free of charge (with new products or remanufactured components) as appropriate.

The above warranty rules do not apply to the following cases:

- (I) Any product damaged due to abnormal use or conditions, accidents, improper handling, human negligence, unauthorized modification, improper use, improper installation or maintenance, or improper storage;
- (II) Products with mechanical serial numbers or electronic serial numbers deleted, altered, or damaged;
- (III) Damage caused by exposure to high temperatures or extreme environmental conditions;
- (IV) Damage caused by connection to or use of accessories or other products not approved or authorized by the company;
- (V) Defects in product appearance, decorations, decorative or structural components such as frames and non-operational parts;
- (VI) Damage caused by external factors such as fire, mud, sand, battery leakage, fuse blowout, theft, or improper use of any power supply.

5.2 Service and Support

If you have any questions about this product, please contact the dealer or authorized service center in your area, or call 400-880-3086 for support and assistance from YunJia Intelligent engineers.

Shenzhen Xtooltech Intelligent Co., Ltd.

Company address: 17&18/F, A2 Building, Creative City, Liuxian Avenue, Nanshan District, Shenzhen

Factory address: 2,3,4/F building 12, Tangtou third industrial zone, Tangtou community, Shiyan street, Bao'an District, Shenzhen

Service-Hotline: 0086-755-21670995/86267858

Email: marketing@XTOOLtech.com

Fax: 0755-83461644

Website: www.XTOOLtech.com

Compliance Information

FCC Compliance

FCC ID:2AW3IF520

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference

This device must accept any interference received, including interference that may cause undesired operation.

Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment can generate, use and radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Responsible Party

Company name: FCC US Agent, LLC

Address: 3722 Illinois Avenue, Saint Charles, IL, 60174, USA

E-mail: Support@FCCUSAgent.com

ISED Statement

IC:29441-F520

HVIN:F520

PMN:XTireProbe

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

CE

Declaration of conformity

Herby, Shenzhen Xtooltech Intelligent Co., Ltd. declares that this TPMS Diagnostic Tool, XTireProbe is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product allowed to be used in all EU member states.

UKCA

Herby, Shenzhen Xtooltech Intelligent Co.,Ltd. declares that this TPMS Diagnostic Tool, XTireProbe satisfies all the technical regulations applicable to the product within the scope of UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulations (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091) and declare that the same application has not been lodged with any other UK Approved Body.